

# Sash - Vent Formulas

## Finished Vent / Sash Size

1901 PW Vent	
Width -	2.7500
Height -	2.000

1900 SH Sash	
Width -	2.6875
Height / 2 -	0.7500

1920 HS Vent	
Width / 2 -	0.6250
Height -	2.625

1930 HS Vent	
Width / 4 -	0.750
Height -	2.625

1930 HS Vent	
Width / 3 -	0.5625
Height -	2.625

Casement Sash	
Width -	1.4375
Height -	1.4375

2901 PW Vent		
Width -	1.9375	Outside
Height -	1.1875	
Width -	2.000	Inside
Height -	1.1875	

2900 SH Sash	
Width -	1.875
Height / 2 -	0.1875

5900 DH Sash	Bottom	Top
Width -	2.875	3.750
Height / 2 -	0.625	0.625

2920 HS Vent	
Width / 2 -	0.5625
Height -	1.250

Awning Vent	
Width -	1.4375
Height -	1.4375

Patio Door Panel	
Width / 2 +	1.250
Height -	1.9375